




SUPERMAX™





Replacement Parts

No.	Part No.	Description	Part No. Includes*
1**	RA-SC1	Motor - Mono Phase 0,37kW	1
	RA-SD1	Motor - Mono Phase 0,55kW	1
	RA-SD3	Motor - Tri Phase 0,55kW	1
	RA-SE1	Motor - Mono Phase 0,75kW	1
	RA-SE3E2	Motor - Tri Phase 0,75kW	1
	RA-SF1	Motor - Mono Phase 1,10kW	1
	RA-SF3E2	Motor - Tri Phase 1,10kW	1
	RA-SG1	Motor - Mono Phase 1,50kW	1
	RA-SG3E2	Motor - Tri Phase 1,50kW	1
	RA-SH1	Motor - Mono Phase 2,20kW	1
	RA-SH3E2	Motor - Tri Phase 2,20kW	1
2	R355612SS	Seal plate incl Mechanical Seal	1
3	R351094	Pump base	1
4	R351090	Locking ring	1
5	R350091	Lid	1
6	R357255	O-ring for Lid	1
7	R357297	Housing BSP - Black	1
8	R357161	Drain Plug & O-ring	2
9	R355621	Bolt & Washer	4
10	R355619	O-ring	1
11	R154492	Seal	2
12	R355334	Screw	3
13	R355618	Diffuser 0,37kW - 1,10kW	1
	R355360	Diffuser 1,50kW - 2,20kW	1
14	R354290	Bolt	4
15	R355174M	Impeller 0,37kW	1
	R355174	Impeller 0,55kW	1
	R355074	Impeller 0,75kW	1
	R355086	Impeller 1,10kW	1
	R355614M	Impeller 1,50kW	1
	R355168M	Impeller 2,20kW	1
16	R355389	Impeller lock screw	1
17	R353253	Mechanical seal	1
18	R355667	Basket	1
19	R170450	Union Kit 50mm	2
	170451	Union Kit 1-1/2"	2
	P-SFL-OSET	Seal set (Partn° 6, 10, 11, 17)	

* PART NUMBER INCLUDES REQUIRED QUANTITY PER PRODUCT

** SEE MOTOR SHEET FOR MOTOR SPARE PARTS



SUPERMAX™

